

DESIG	CP	DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA
CHECK	KBD \	APPROVED	DRAWING NO. REV. E
	M.lk	#	DSI 9250 SHEET 1 OF
DATE			TITLE SCALE
06.1	1.22		BASKET CONVERSION KIT NTS
Α		03.02.17	NEW ISSUE
В		06.11.22	ADD NAS1515H4 WASHERS, REF DSI9318

## **DART SERVICE INSTRUCTION**


TO AMEND INSTALLATION INSTRUCTIONS D350-607 REV. F

REF. CANADIAN STC: SH94-14 REF. FAA STC: SR00213NY

THE D350-607-041 HELI-UTILITY-BASKET™CAN BE CONVERTED TO A D350-607-043 AS FOLLOWS:

- REMOVE D350-607-041 BASKET FROM THE AIRCRAFT.
- 2. REMOVE D2512 LID ASSEMBLY BY REMOVING QTY (2) AN4-7A BOLTS OR D2569 HINGE.
- IF REQUIRED, WELD QTY(2) D2581 MOUNTING BRACKETS ONTO THE D2221 BASE AS SHOWN BELOW TO LINE UP WITH THE D2581 BRACKETS ON D2989-041 LID. USE ER308L FILLER ROD.
- 4. LOCATE D2989-043 LID ON BACK-SIDE OF D2512 LID. TRANSFER DRILL QTY (5) Ø0.257 HOLES FROM D2989-043 TO D2221 BASE. DE-BURR AND TOUCH UP WITH PAINT.
- 5. INSTALL D2989-043 LID USING QTY (5) AN4-22A BOLTS AND ASSOCIATED HARDWARE.
- 6. INSTALL D2989-041 LID ONTO D2989-043 LID USING QTY (2) AN4-13A BOLTS AND ASSOCIATED HARDWARE AS SHOWN IN SERVICE INSTRUCTION DSI9318 REV. A.
- 7. INSTALL D2856-400-720 ABRASION STRIPS PER ITEM 5 OF THE INSTALLATION PROCEDURE ON PAGE 4 OF D350-607 REV. F.
- 8. REINSTALL BASKET ON AIRCRAFT PER D350-607 REV. F AS D350-607-043.

QTY	Part Number	Description
Х	DSI9250-011	BASKET CONVERSION KIT
5	D2022 101	CDACED
	D2022-101	SPACER
1	D2258-200	LABEL
1	D2332-041	PROP ASSEMBLY
1	D2530	HANDLE WELDMENT
2	D2535	SPRING
2	D2537	BUSHING
2	D2581	MOUNTING BRACKET
4	D2856-400-720	ABRASION STRIP
1	D2989-041	BASKET LID ASSEMBLY (OUTSIDE)
1	D2989-043	BASKET LID ASSEMBLY (INSIDE)
2	AN3-16A	BOLT
2	AN4-13A	BOLT
7	AN4-22A	BOLT
4	AN5-17A	BOLT
14	AN960JD416	WASHER
2	AN960JD416L	WASHER
4	AN960JD516	WASHER
4	AN970-4	WASHER
2	MS21042L3	NUT (OR MS21042-3)
9	MS21042L4	NUT (OR MS21042-4)
4	MS21042L5	NUT (OR MS21042-5)
2	NAS1515H4	WASHER



Copyright © 2003 by DART AEROSPACE LTD